



Click Share Operation

Use to connect up to 4 laptops to the TV to share views. The device sets up automatically the screen resolutions and will transmit audio to the Bose speaker system.


1. Locate the Click Share (Barco) pucks under TV.




Plug into laptop usb port.

Program will open window below

Click open file to view files




Double click either Windows or Mac





You will see an icon in the lower right



Now press silver button on Clickshare puck that is plugged into usb port. Light around silver button will turn red to indicate you are sharing with screen.

When you want to stop sharing to screen, either momentarily or when finished press silver button again and the silver circle will then be white. If you would like to connect to the screen again just press silver button again.

If you are ready to disconnect laptop from Click share, go to hidden icons on computer and then right click on the usb icon and press exit or disconnect as you would a normal usb device.

Audio from Click share device

To play audio from laptop to Clickshare via speakers in ceiling.

Locate Bose keypad on wall.

Use the "Select" buttons on the left side of keypad and locate "Conf TV"

1. Use volume buttons on Bose Keypad to adjust audio
Note: you may have to make adjustments on your laptop device to allow auto to play on an external source.